



TOTE SPRAYER APPLICATION PROCEDURE FOR MEDIUM TO LARGE PROJECTS

275 GALLON TOTE / 48,460 SQ. FT. COVERAGE

1. Prior to beginning the T°Cool application process calibrate walking speed and spray velocity by filling sprayer with water and spraying a known square footage. Adjust walking speed and velocity as necessary
2. It is recommended that the application process is executed in two passes over turf area at right angles to each other
3. Open tote of T°Cool and blend vigorously to smooth homogenous consistency
4. The blending can be accomplished with a tote blender or using the tote sprayer and recirculating T°Cool for twenty minutes
5. Using a tote spraying device apply the appropriate amount of T°Cool solution to the targeted square footage of synthetic turf system. Walk at same speed as your walking speed during calibration step
6. After applying T°Cool, immediately and lightly rinse off synthetic turf blades removing any T°Cool from turf blades and rinsing the residue into the textile layer
7. **Allow the T°Cool to completely dry / cure after application either at ambient conditions or accelerated by a heat source. This is a crucial step!**
8. After the Turf system has completely dried the T°Cool will be cured / cross-linked and provide long term super absorbency and cooling